

PEDICUTE™ PORTABLE SPA

OWNERS MANUAL



pedicute™
BY CONTINUUM
FOOTSPAS



IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance.

When using an electrical appliance, basic precautions should always be followed, including the following:

DANGER

To reduce the risk of electric shock:

- 1) Always unplug this appliance from the electrical outlet immediately after use and before cleaning.
- 2) Do not reach for an appliance that has fallen into water. Unplug immediately.
- 3) Do not use while in the bath or in the shower.
- 4) Do not place or store appliance where it can fall, or be pulled, into a tub or sink.
- 5) Do not place or drop into water or other liquid.

WARNING

To reduce the risk of burns, electric shock, or injury:

- 1) Appliance should never be left unattended when plugged in. Unplug from outlet when not in use.
- 2) Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- 3) This appliance should not be used by, or near, children or individuals with certain disabilities.
- 4) Use this appliance only for its intended use as described in this manual.
Do not use attachments not recommended by Continuum Footspas.
- 5) Never operate this appliance if it has a damaged cord or plug. If it is not working or if it has been dropped, dropped in water, or damaged, contact Continuum Footspas service center for examination and repair.
- 6) Do not carry this appliance by supply cord or use cord as a handle.
- 7) Keep the cord away from heated surfaces.
- 8) Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair and other debris.
- 9) Never drop or insert any object into any opening.
- 10) To disconnect, turn all controls to the OFF position, then remove plug from the outlet.
- 11) Do not use outdoors.
- 12) Do not operate where aerosol (spray) products are being used or where oxygen is administered.
- 13) Do not attempt to plug or unplug unit while feet or other body parts are in the water.
- 14) **DO NOT STAND ON OR IN THE FOOT MASSAGER (PEDICUTE). USE ONLY WHILE SEATED. PLACE FEET IN MASSAGER AND REMOVE FEET FROM MASSAGER ONLY WHILE IN A SEATED POSITION.**
- 15) Never operated on a soft surface, such as a bed or couch, where air openings may be blocked.
- 16) Use heated surface carefully as it may cause serious burns. If utilizing heating surface only, (dry massage) one **MUST** use the lowest heat setting only. Do not use over sensitive areas or in the presence of poor circulation. The unattended use of heat by children or incapacitated persons may be dangerous.
- 17) **DO NOT** use cracked, leaking, or otherwise damaged tub with the heating/vibrating unit.
- 18) This appliance is designed for professional use only.

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

To reduce the risk of electric shock, this appliance has a grounded plug. This plug will fit into a grounded outlet. If it does not fit, contact a qualified electrician to install a proper outlet.

DO NOT CHANGE THE PLUG IN ANYWAY.

CAUTIONS

The Pedicute™ should not be used if the following cases are present: tuberculosis, benign and malignant tumors, hemorrhages, inflammations of the skin, phlebitis or thrombosis, open or fresh wounds, bruises, broken skin or varicose veins, undetermined calf pain, or joint pain.

- Consult a physician if you have any questions regarding therapeutic use of this product.
- Consult a physician before using if clients are experiencing unexplained pain, swollen muscles, or if they have recently sustained a serious muscular injury.
- Keep away from children.
- Discontinue use of massager/heater if pain increases or swelling occurs after application.
- If clients are pregnant, please consult a physician before using.

IMPORTANT NOTICE

In order for the Pedicute to function properly it must operate at room temperature (at least 65°F). If for any reason it is not at room temperature and one tries to activate the basin heater, the heating lights will continually blink. This is normal and once the unit is at room temperature the basin heater will function normally.

USER/MAINTENANCE INSTRUCTIONS

The Pedicute massaging/heating platform is designed for use in a professional salon environment only with The Pedicute tub or as dry heated foot massager.

- 1) Make sure massager/heater is in OFF position.
- 2) Fill tub with warm water and place Pedicute tub on top of the massager and plug massager into wall outlet. Never plug or unplug the massager/heater while client's feet are in the water. To eliminate splashing, do not fill tub with more than 1 and 1/2 gallons of water (approximately 2.5 inches deep). Do not fill Pedicute tub to capacity.
- 3) The heat setting is desired to maintain the temperature of warm water, not to heat cold, or room temperature water.
- 4) Have clients sit in a chair and place feet in the water. **NEVER STAND IN THE PEDICUTE.**
- 5) Turn Pedicute massager heater on by pressing the ON/OFF button and select setting on the touchpad located on the unit.
- 6) Select one or a combination of the settings below:
 - Vibration and Heat (combination High/Low of vibration and heat)
 - Heat High/Low (heat only)
 - Vibration High/Low (vibration only)
- 7) To turn off, simply press the OFF button on the touch pad.
- 8) To select heat High/Low/Off press the heat button one, two, or three times.
- 9) To select vibration High/Low/Off press vibration button one, two, three or four times (for power massage).
- 10) Pedicute massager/heater can also be used as a dry foot massager when used without water. Attention: use heat on low setting for dry use (without Pedicute Tub) to prevent burning.
- 11) Do not hang unit from power cord.
- 12) To clean Pedicute massager/heater, wipe with a damp cloth (Never submerge unit in water). Do not use any strong chemical cleaners such as benzene or acetone.
- 13) **CHECK WITH YOUR STATE BOARD FOR SPECIFIC CLEANING AND/OR SANITIZING REQUIREMENTS.**

CONTROL FEATURES

Touchpad controls combine custom settings:

- 1) ON/OFF (OFF will turn unit off and reset previous setting).
- 2) Vibration and Heat (combinations Hi and Low heat and vibration).
- 3) **Heat Only**
 - a. Press heat button one time LOW. (Low heater light lit).
 - b. Press heat button two times HIGH. (HI heater light lit).
 - c. Press heat button three times for POWER HEAT. (Both heater lights lit).
 - d. Press heat button four times to turn heat OFF.
- 4) **Massage Only**
 - a. Press vibration button one time LOW. (Low vibrating light lit).
 - b. Press vibration button two times HIGH. (HI vibrating light lit).
 - c. Press three times for POWER MASSAGE (both vibrating lights lit). Power Massage setting is not recommended for use with the Pedicute tub. Power Massage setting may cause water to splash.
 - d. Press four times to turn vibration OFF.

Heater/Massager has automatic shut off (standby) feature. The massage will shut off after 35 minutes. The heat will shut off after 45 min. Simply push either the Heat or Massage button to restart the settings.

ALWAYS TURN UNIT OFF AFTER USE.

ASSEMBLY INSTRUCTIONS

Attaching Center Foot Support Cushion to Telescoping Tube

- 1) Extend Telescoping Tube to maximum height and tighten black tension knob to secure.
- 2) Locate Center Foot Support Cushion. Position cushion over top of telescoping tube making sure hole in cushion aligns with silver push pin located on telescoping tube. Depress push pin at the same time as you push down slightly on cushion. When push pin aligns with cushion hole, it will snap into place.

DANGER! ELECTRIC CORDS CAN BE HAZARDOUS.

Misuse Can Result in Fire or Death by Electric Shock During Use.

- Keep Children and Pets Away from Cord.
- **Avoid Overheating.** Uncoil Cord and Do Not Cover it with any Material.
- Do Not Drive, Drag, or Place Objects over Cord.
- Fully Insert Plug into Outlet.
- Do Not Remove, Bend or Modify Any Metal Prongs or Pins of Cord or GFCI.
- Do Not Run Cord Through Doors Ceiling, Walls or Floors.

After Use

- Grasp Plug to Remove from Outlet.
- Always Store Indoors.
- Always Unplug When Not in Use.
- Do Not Unplug by Pulling on Cord.

Continuum Footspas Limited Warranty

Continuum Footspas has designed and manufactured their pedicure chairs to the highest standards. Accordingly, Continuum Footspas expressly warrants their pedicure chairs as follows:

To the original owner of our pedicure chairs, Continuum Footspas may repair or replace, at its option, any pedicure chairs found to be defective in material or workmanship upon inspection by a factory authorized representative of Continuum Footspas.

This limited warranty covers the following:

This Limited Warranty covers parts and components. It also covers all Continuum Models for a period of one (1) year from date of shipment except as noted below:

- **Maestro Model:** Two (2) years from Date of Shipment (DOS).
- **Maestro Solid Surface Basin:** Five (5) years from DOS.
- **LE Chair Only:** Two (2) years from DOS.
- **Fiberglass Basin:** Two (2) years from DOS.
- **Shipping Costs Associated with Warranty Parts:** One (1) year from date of shipment. Continuum will cover normal domestic shipping costs. Expedited and/or International shipping will incur additional charges
- **Solid Surface Echo Basin:** Five (5) years from DOS.
- **Vibra-Massage + Heat System:** Two (2) years from DOS.
- **Replacement Parts (Non-Warranted):** Ninety (90) days from DOS.
- **Accessories:** Ninety (90) days from DOS.
- **Labor - All Models Except as Noted below:** One (1) year from the date of shipment. Continuum Footspas will cover reasonable labor costs associated with the installation of replacement parts found to be defective in material or workmanship upon inspection by a factory authorized representative of Continuum Footspas. **NOTE EXCEPTIONS BELOW. No labor costs or replacement parts will be covered under this Limited Warranty, if at the sole discretion of Continuum Footspas, it is determined a failure was caused by negligence, accident or improper use, improper installation or lack of proper maintenance as outlined in the Owner's Manual.**

The exchange of a pedicure chair is limited to supplying a replacement pedicure chair of equal style. Owner is responsible for all labor and shipping costs necessary to replace a pedicure chair.

NO CONSEQUENTIAL, INCIDENTAL, CONTINGENT, INDIRECT, SPECIAL OR OTHER DAMAGES WILL BE ALLOWED WHATSOEVER. This limited warranty is null and void if the pedicure chair is removed from its original installation, or is not installed in accordance with specifications of Continuum Footspas, or national, state or local codes, regulations and ordinances. Furthermore, this Limited Warranty is null and void if the pedicure chair is subjected to improper installation or maintenance, negligence, improper cleaning or any other circumstances beyond Continuum Footspas control. In order for your Limited Warranty to be valid, your pedicure chair must be installed by a licensed professional in accordance with Continuum Footspas installation instructions.

EXCLUDED FROM LIMITED WARRANTY:

- 1) Unauthorized repairs.
- 2) Damage due to freight, accident, natural disaster and/or abuse.
- 3) Staining, fading or discolorization of the seat, seat back, armrests, leg supports and footrests.
- 4) Damage or malfunctions due to improper installation including but not limited to, failure to comply with all national, state and local plumbing, electrical and building codes.
- 5) Fading, discoloration or staining of any part due to improper water additives, hard water or harmful cleaning agents or chemicals.
- 6) Damage to drain pump due to obstruction in drain hose and/or debris in pump impeller housing.

Parts and/or circumstances for which Labor is NOT COVERED - Parts Noted Below Are Simple to Replace and DO NOT Require a Service Technician.

- Jet Cover and/or Impeller
- Footrest/Leg Supports
- On/Off Air Actuated Button
- Pedicute Model
- Replacement of black plastic parts
- Faucet Cartridge and/or Filler-Sprayer
- Roller Massage or Vibra-Massage + Heat System
- Any LED Light
- Any International Shipments including but not limited to Canada and Mexico
- Handheld Control Wands
- Manicure Trays
- Replacement Upholstery

For service or information regarding this limited warranty, please contact.

Continuum Footspas, LLC • P.O. Box 363 Brookfield, WI 53008
Toll Free: 1 877 255 3030 • Telephone: 262 754 4900 • Service: 262 777 2248 • Fax: 262 754 4901 • MyContinuumPedicure.com

This Limited Warranty is to the original owner and is not transferable. The original owner agrees by using Continuum pedicure chairs the obligation of Continuum Footspas shall not extend to indirect or contingent damages or injury. Furthermore, the obligations of Continuum Footspas are limited to those set forth herein. This limited warranty is the exclusive remedy and is in lieu of all other warranties, express or limited, including, but not limited to, any implied warranty of fitness or merchantability for a particular purpose. No distributor, dealer or other person has the right or authority to bind Continuum Footspas to changes to this limited warranty. Consequently, Continuum Footspas is not responsible for such warranties or representations.

ADDITIONAL PROVISIONS

- Any assistance Continuum Footspas provides to the original owner above and beyond the scope of this limited warranty does not constitute a waiver of such terms, limitations or exclusions. Furthermore, such assistance does not extend this Limited Warranty.
- Continuum Footspas shall not be liable for any other obligations or liabilities as a result of breach of contract of warranty, negligence or strict liability with regards to their pedicure chairs.
- This Limited Warranty applies only to pedicure chairs installed in any one of the fifty (50) States of the United States, the District of Columbia or provinces of Canada.